
&Tradition


Loafer SC107

Space Copenhagen

2025



Product Fact Sheet



H: 74 cm / 29.13 in
Seat H: 44.5 cm / 17.52 in

W: 60 cm / 24.62 in
D: 62 cm / 24.62 in. Seat D: 47.5 cm / 18.70 in

Loafer SC107
Space Copenhagen
2025




Gentle 0193


Sisu 0655


Barnum 24


Cifrado 0771


Ecriture 0470

Product description
Club chair

Environment
Indoor

Material
Wood-based board, Cardboard, Foam, Wadding, Dust cover, Lining, Velcro, Zipper band, Zipper head, Leg, Felt pad, Fabric.

Production process
The frame is made from wood, which is then layered with wadding and foam. The chair is finished with upholstery.

Variants
Available in a variety of fabrics.

COM - Material consumption
Fabric usage: 2.4 meters based on 140cm roll.
Leather usage: 5.4 square meters based on a yield of 60% pr hide. COM must be approved by &Tradition to ensure suitability for upholstery.

Dimensions
H: 74 cm / 29.13 in
W: 60 cm / 24.62 in
D: 62 cm / 24.62 in
Seat H: 44.5 cm / 17.52 in
Seat D: 47.5 cm / 18.70 in

Weight
15.2 kg

Certifications

FSC® Mix 70%

Gliders
Plastic gliders as standard

Impact
- Made in a factory powered by certified renewable energy.
- Uses FSC® certified wood, supporting responsible management of the world's forests.
- Uses certified low emission upholstery foam, ensuring it does not contain harmful chemicals that may pollute indoor air.
- Available with EU Ecolabel certified top fabrics, ensuring low emissions of polluting chemicals and high workplace standards.

Manufacturer
Produced in Lithuania by UAB Baltic Sofa

Cleaning Instructions
Please see our Maintenance & Care instructions here

&Tradition®



SC107


Recycling & Disassembly

Loafer SC107

Recycling
Your Loafer chair is built to last and we hope that it will serve you for many years to come. The chair is covered with high quality fabric and can be easily separated from its base.
All fabric, foam and wooden parts can be separated and delivered to a suitable recycling station.


Spare parts
To purchase spare parts, please write to our sales support team at info@andtradition.com with your query.

5 year warranty
&Tradition provides a 5-year warranty with every Loafer. This warranty covers any faults present at the time of purchase, or those that may have occurred as a result of a manufacturing defect. The warranty is valid from the date stated on the original invoice.




Disassembly


1. Begin the disassembly process by removing the cushion from the base.



2. To separate the cushion into its components, open the zipper and remove the foam from the inside of the fabric sleeve.



3. Flip the chair upside down by placing it on the backrest and seat as illustrated. Ensure you have an additional person to help perform this action safely.




4. Remove the gliders from the base of the chair by pulling them out using a pair of pliers. Once the gliders have been removed, separate the MDF board from the chair base.

&Tradition®


Recycling & Disassembly

Loafer SC107





Disassembly

5. Carefully cut open the back of the seat along the dotted line shown in the illustration using a knife or scissors.



6. Unscrew the fasteners inside the seat that connect it to the main frame. Turn them counter clockwise to remove them. Once all bolts have been removed, you can separate the seat from the chair.






7. To disassemble the seating panel, remove the staples along the dotted lines indicated in the illustration. Use a pair of pliers or a small flathead screwdriver to carefully pry them out.

&Tradition®


Recycling & Disassembly

Loafer SC107




Disassembly


8. Seperate the fabric from the base.




9. Carefully remove the foam padding from the wood using a spatula to scrape it off.



10. Remove the staples securing the fabric straps to the wooden frame to separate the straps from the wood.






11. Next, remove the staples along the dotted lines shown in the illustration. Use a pair of pliers or a small flathead screwdriver to carefully pry them out.

&Tradition®


Recycling & Disassembly

Loafer SC107




Disassembly


12. Carefully cut open the fabric along the dotted lines as illustrated with scissors or a knife. Once cut, pull the fabric halfway down to separate it from the frame.



13. Return the chair to its original upright position and gently separate the fabric by pulling it up and away from the chair. Ensure you have an additional person to help perform this action safely.



14. Using a spatula, carefully remove the foam padding by scraping it off the wooden base.



15. Dispose of the wooden base at a suitable recycling station. If necessary, break it down into smaller pieces for easier disposal.

16. Finally, dispose of all components using the appropriate recycling streams.

&Tradition®